

instructions for barcode readers

HD8900



Teclado USB HID

USB HID Keyboard



USB Virtual RS232

USB Virtual RS232

