

instructions for barcode readers

HD-S80



Manual mode



Automatic mode



Continuous mode

