

instructions for barcode readers

HD71



Factory reset

