


instructions for barcode readers

HD-MS300



Ton an

Sound on



Ton aus

Sound off

