

instructions for barcode readers

HD-MS300



Ustaw Enter jako suffix

Add Enter Suffix



Usun' sufiks

Delete suffix

