


instructions for barcode readers

HD-SL99



Manual mode



Continuous mode

