


instructions for barcode readers


HD-SL99




Mute the receiver volume




Low receiver volume




Medium receiver volume




High receiver volume




Turn off the scanner's sound




Turn on the scanner's sound



Low scanner volume



Medium scanner volume



High scanner volume

