

# instructions for barcode readers

---

**HD-SM1000**



## **Shakel read all 1D Codes in**

**Enable read all 1D Codes**



**Shakel read all 1D Codes uit**

**Disable read all 1D Codes**



## **Shakel read all 2D Codes in**

**Enable read all 2D Codes**



**Shakel read all 2D Codes uit**

**Disable read all 2D Codes**

