

instructions for barcode readers

HD200



Continuous mode



Manual mode



Automatic mode on



Automatic mode off

