

# instructions for barcode readers

---

**HD201**



## Kontinuierlicher Modus

Continuous mode on



# Manual mode

## Manual mode



**Auto mode on**

**Automatic mode on**



## **Auto mode off**

### **Automatic mode off**

