

# instructions for barcode readers

---

**HD201**



## Continuous mode on



## Manual mode



## Automatic mode on



## Automatic mode off

