

# instructions for barcode readers

---

**HD201**



## Modo continuo

Continuous mode on



## Modo manual

### Manual mode



## Modo automático encendido

Automatic mode on



## Modo automático desactivado

Automatic mode off

