

instructions for barcode readers

HD21



Mute volume



Low volume



Medium volume



High volume

