

# instructions for barcode readers

---

**HD21**



## **Ustaw suffix STX**

**Add STX Prefix**



## **Pokaż identyfikator kodu**

**Show code id prefix**



## Ukryj identyfikator kodu

Hide code id prefix

