

instructions for barcode readers

HD29A



Manual mode

Manual mode



Auto mode

Automatic mode



Kontinuierlicher Modus

Continuous mode

