

instructions for barcode readers

HD29A



Interface USB

Interface USB



Interface RS232

Interface RS232



Automatic Identification

Automatic Identification



Interface USB virtuel RS232

Interface USB virtual RS232

