

# instructions for barcode readers

---

**HD29A**



# Handmatige modus

Manual mode



## **Automatische modus**

**Automatic mode**



## **Continue modus**

**Continuous mode**

