


instructions for barcode readers

HD42



USB-HID-Tastatur

USB HID Keyboard



RS-232

RS-232

