


instructions for barcode readers

HD42



Clavier USB HID

USB HID Keyboard



RS-232

RS-232

