

# instructions for barcode readers

---

**HD42A**



## Low tone



## High tone



## Mute volume



## Middle volume



## High volume



## Low volume

