

# instructions for barcode readers

---

**HD42A**



## **Tono basso**

**Low tone**



**Tono alto**

**High tone**



## Mute volume

Mute volume



## **Volume medio**

**Middle volume**



## **Volume alto**

**High volume**



## **Volume basso**

**Low volume**

