

# instructions for barcode readers

---

**HD42A**



## **Baud-snelheid 9600 bits**

**Baud rate 9600 bits**



## **Baud-snelheid 14400 bits**

**Baud rate 14400 bits**



## **Baud-snelheid 19200 bits**

**Baud rate 19200 bits**



**Baudsnelheid 57600 bits**

**Baud rate 57600 bits**



**Baudrate 115200 bits**

**Baud rate 115200 bits**



## Gegevens 8 bits

Data 8 bits



## Gegevens 7 bits

Data 7 bits





# 1 Stopbit

1 Stop bit



**2 Stop bit**

**2 Stop bit**

