


instructions for barcode readers

HD42A



Interfejs USB

Interface USB



Interfejs RS232

Interface RS232

