

instructions for barcode readers

HD43



Sound off



Low volume



Middle volume



High volume

