

instructions for barcode readers

HD43



Audio Disattivato

Sound off



Volume basso

Low volume



Volume medio

Middle volume



Volume alto

High volume

