

instructions for barcode readers

HD43



Abilita l'ASCII completo Code39

Enable Code39 full ASCII



Disabilitare il codice39 completo ASCII

Disable Code39 full ASCII



Abilita UPC su EAN-13

Enable UPC to EAN-13



Disabilita UPC in UPC-A

Disable UPC to UPC-A



Abilita ISBN

Enable ISBN



Disattiva codice ISBN

Disable ISBN



Abilita Code32

Enable Code32



Disabilitare Code32

Disable Code32



Abilita MSI

Enable MSI



Disable MSI

Disable MSI

