

instructions for barcode readers

HD43



Handmatige modus

Manual mode



Continue modus

Continuous mode

