

instructions for barcode readers

HD610A



Dauermodus eingeschaltet

Continuous mode on



Manual mode

Manual mode

