

# instructions for barcode readers

---

**HD610A**



## Interface USB Virtual COM

