

instructions for barcode readers

HD610A



Interface USB Virtual COM

