

# instructions for barcode readers

---

**HD610A**



## Restablecimiento de fábrica

### Factory reset



# Interfaz USB virtual COM

## Interface USB Virtual COM



# Anadir Enter Sufijo

**Add Enter Suffix**



# Cancel Enter

Cancel Enter



## Modo continuo en

Continuous mode on



## Modo manual

### Manual mode



## Sonido encendido

Sound on





# Sonido apagado

Sound off



## Velocidad en baudios 115.200 bits

Baud rate 115200 bits



## Velocidad de baudios 9600 bits

**Baud rate 9600 bits**

