


instructions for barcode readers

HD610A



Modalita continua attiva

Continuous mode on



Modalita manuale

Manual mode

