


# instructions for barcode readers

---


**HD70**



## Real mode




## Storage mode



## Upload data from memory



## Amount of data in memory



## Memory cleaning

