


instructions for barcode readers


HD70




Real mode




Storage mode



Upload data from memory



Amount of data in memory



Memory cleaning

