


instructions for barcode readers


HD73



Enable Code32



Disable Code32



Extended code39 enabled



Extended code39 disabled



Enable UPC-E to UPC-A



Disable UPC-E to UPC-A



Enable UPC-A to EAN13



Disable UPC-A to EAN13



Enable EAN13 to ISSN



Disable EAN13 to ISSN



Enable EAN13 to ISBN



Disable EAN13 to ISBN

