

# instructions for barcode readers

---

**HD75**



## Factory reset



## Connection Bluetooth



## HID mode



## SPP mode



## Real mode



## Storage mode



## Upload data from memory





## Amount of data in memory



## Memory cleaning



## Sound on



## Sound off



## Sleep time after 30 sec



## Sleep time after 60 sec



## Sleep time after 2 min



## No sleep

