

instructions for barcode readers

HD8900



Real mode

Real mode



Speichermodus

Storage mode



Daten aus dem Speicher hochladen

Upload data from memory



Batteriestatus

Battery status

