

instructions for barcode readers

HD8900



Volume alto

High volume



Volume medio

Middle volume



Volume basso

Low volume



Mute volume

Mute volume



Tono alto

High tone



Tono medio

Middle tone



Tono basso

Low tone

